

Release Notes for:

**AV Bridge MatrixMIX****Release Information:**

-----

6/13/2018

AV Bridge MatrixMIX 1.1.0

Notes:

- AV Bridge MatrixMIX and PCC MatrixMIX must both be updated to 1.1.0 to work properly together
- New Features
  - Added support for DocCAM 20 HDBT and RoboSHOT IW.
  - Added ability to configure IP streaming packet sizes.
  - Added thumbnail images for keying sources and controls in the web UI.
  - Added telnet commands to control input configuration.
  - Added telnet command to query streaming status.
  - Added a telnet command to allow monitoring of physical button presses for AV Bridge MatrixMIX.
  - Added ability to toggle auto mic mixer inputs by clicking on the LED icons in the web UI.
  - Added camera standby control on the AV Bridge MatrixMIX admin web UI.
  - Added advanced chroma key threshold configuration options.
  - Added ability to disable general HTTP access to the device.
  - Added ability to configure HTTPS certificates from the web UI.
  - Added ability to disable the telnet server on the device.
  - Added the ability to import configurations from previous versions of software
  - Added ability to Pan-Tilt-Reset cameras
- Improvements
  - Improved controls for static graphics positioning and assignment in the web UI.
  - Various security improvements including disabling the TLS v1.0 protocol and DES and 3DES TLS cyphers
  - Increased number of available software triggers to 50.
  - Improved serial camera preset detection.
- Known Issues
  - Video may temporarily freeze if the system is switched between dual bus and A/B mode while a static graphic layer is active. Turning the layer off and rebooting the AV Bridge MatrixMIX should resolve the issue.
  - Under certain conditions an uploaded static graphic image may not work properly. Deleting and reloading the image should fix the issue.
  - Hot plugging of inputs can occasionally cause temporary color distortion in the image.

-----

3/13/2018

AV Bridge MatrixMIX 1.0.1

Notes:

- Added support for HID-based 3M touchscreen monitors.

-----

8/30/2017

AV Bridge MatrixMIX 1.0.0

Notes:

- Initial Release

**Additional Information:**



For instructions on how to update your firmware, please see the product installation guide on our website at [www.vaddio.com](http://www.vaddio.com)

Thank you for your continued support of Vaddio products. Please contact Vaddio with any questions at 763-971-4400 or through our website.