

Release Notes for:

## **PCC MatrixMIX**

### **Release Information:**

-----

6/13/2018

PCC MatrixMIX 1.1.0

Notes:

- AV Bridge MatrixMIX and PCC MatrixMIX must both be updated to 1.1.0 to work properly together
- New Features
  - Added support for DocCAM 20 HDBT and RoboSHOT IW
  - Added ability to disable general HTTP access to the device
  - Added ability to configure HTTPS certificates from the web UI
  - Added ability to disable the telnet server on the device.
  - Added a telnet command to allow monitoring of physical button presses for PCC MatrixMIX.
  - Added telnet command to set hostname/IP for targeted PCC MatrixMIX unit.
  - The ability to import configurations from previous versions of software
  - Added ability to Pan-Tilt-Reset cameras
- Improvements
  - Various security improvements including disabling the TLS v1.0 protocol and DES and 3DES TLS cyphers
  - The PCC MatrixMIX will now be able to label presets properly
- Known Issues
  - The PCC MatrixMIX menu knob can become temporarily stuck in the red state under certain circumstances. Rebooting the PCC MatrixMIX should resolve the issue.
  - Some audio configuration changes on a connected AV Bridge MatrixMIX unit may cause the PCC MatrixMIX touch UI audio tab to become non-functional until the PCC MatrixMIX is disconnected and reconnected, or until the PCC MatrixMIX is rebooted.

-----

8/30/2017

PCC MatrixMIX 1.0.0

Notes:

- Initial Release

### **Additional Information:**

For instructions on how to update your firmware, please see the Integrator's Complete Guide on our website at [www.vaddio.com](http://www.vaddio.com)

Thank you for your continued support of Vaddio products. Please contact Vaddio with any questions at 763-971-4400 or through our website.